


Correa maquina de coser 603975-011

603975-011



Correa maquina de coser 603975-011

Caractéristique	Valeur
Marca	Singer
Modelo	4552
Modelo	5910
Modelo	6231
Modelo	6233
Modelo	6234
Modelo	6235
Modelo	6269
Modelo	7028
Modelo	9005
Modelo	9008
Modelo	9010
Modelo	9012N606
Modelo	9022
Modelo	9028
Modelo	9042
Modelo	9110
Modelo	9113
Modelo	9117
Modelo	9124
Modelo	9130
Modelo	9210



Modelo	9217
Modelo	9224
Modelo	9240
Modelo	9420
Modelo	9423
Modelo	9432
Modelo	9900
Modelo	6408
Modelo	6412
Modelo	6416
Modelo	6423
Modelo	6267
Modelo	6268
Modelo	9133
Modelo	9137
Modelo	9143
Utilización	Máquina de coser
Marca de la correa	Genérica
Unidad de venta	pieza

